



SECONDARY GUARDING LIFT ENABLE



Skyjack's scissor lifts and vertical mast lifts are designed with a range of safety features in accordance with a variety of global regulatory requirements.

Industry groups have recently suggested possible circumstances, conditions, and operations that might result in inadvertent contact with obstructions and consequently an entrapment hazard. As a result, a form of secondary guarding is now being requested on scissor lifts and vertical mast lifts by some equipment users.

Skyjack recognizes there is no single best solution to help reduce the risk of entrapment, and much depends upon a specific job site risk assessment to determine the most appropriate solution for any particular need or application.





SECONDARY GUARDING LIFT ENABLE



KEY FEATURES

- Robust control box shroud provides additional guarding of controls; reducing the risk of unintended actuation.
- A secondary anti-tamper “enable” button located on the side of the control box.
- “Two handed” operation is required to lift, maintaining the operator’s body in an upright position and away from the railings; mitigating the risk of entrapment.
- Both joystick and secondary enables must be activated to allow the platform to lift; release of either will stop the function immediately.
- The secondary “enable” button is not used for lowering the platform or for driving; which continue to be joystick enable only.
- SGLE is suitable for all Skyjack scissor lift and vertical mast lift models, and is available as a direct factory install or after-market accessory.

www.skyjack.com

Skyjack UK
Unit 1, Maes-y-Clawdd
Maesbury Road Industrial Estate
Oswestry, Shropshire, SY10 8NN
Tel: +44 (0) 1691 676235
Fax: +44 (0) 1691 676239
Email: info@skyjackeurope.co.uk

Skyjack France
74 Rue Sibert
F-42400 Saint-Chamond
France
Tel. +33 (0) 4 78 73 53 32
Fax. +33 (0) 4 78 56 52 42

Skyjack Germany
Därmanbusch 2a
D-58456 Witten
Tel: +49 (0) 2302 20 26 909
Fax: +49 (0) 2302 20 25 671

Skyjack AB/Sweden
Agnesbergsvägen 28
424 38 Agnesberg
Sweden
Tel: +46 (0) 31 21 22 45
Fax: +46 (0) 31 787 65 10



This brochure is for illustrative purpose only and based on the latest information at the time of printing. Skyjack Inc. reserves the right to make changes at any time, without notice, to specifications, standard and optional equipment. Consult the Operating Maintenance and Parts Manuals for proper procedures.

SKYJACK
simply reliable